

## 01763 274 223

## **BFT-FCS**



## FOUNDATION BOX FOR SUB 230V 130 DEG OPERATION

Foundation box for sub 230v 130 deg operation

## **FEATURES**

• Foundation box forsub 230v, 130 deg operation These are handed manual release on the right of the box (DX) on the left of box (SX)