


Basic DG500 Programming Guide



Press # for 2 seconds

1234



Replace a lost Program Code
 Remove power from DG500
 Short between REX/BL & GND
 Apply power to DG500 remove short
 Then # ● light 1234 3 New 4 digit code
 Within 15 seconds

* This will allow a user to control relay1-2 or both